



Innovative
Contamination
Solutions

Proper Surface Wiping Guide

Proper surface wiping procedures to help ensure the best cleaning efficacy



1. Always follow relevant site protocols and procedures; this should include wearing appropriate cleanroom gloves and garments.
2. Fold the wiper into quarter folds. This will provide several clean surface areas and allow better contact with the surface to be wiped.
3. When wiping, hold the wiper so that the folded edge is toward your fingertips. Hold the unfolded edges in your hand. Group the unfolded edges between your thumb and forefinger.
4. Use either a pre-wetted wiper or a dry wiper moistened with an appropriate cleaning agent.



5. Wipe in one direction, overlapping wiped area by 10% to 25%.
6. Wipe from cleanest to least clean regions of the surface being wiped. Wipe systematically, so from top to bottom, or far to near, in a linear vs. circular motion.
7. Be sure to keep track of which surfaces have been cleaned and which wiper areas are unused.
8. Always use the cleanest surfaces of the wiper. If re-wiping, use a clean portion of the wiper, not the used wiper area.
9. Dispose of wipers according to established site procedures.

Prevention is the best policy so please embrace all aspects to protect yourself and others. Teknisat wet wipes are intended to kill the virus on inanimate surfaces, but not intended for use on human skin. We can help keep your environment clean and virus free, but if you feel ill, please get yourself tested and isolate to prevent potential spread.



To learn more,
call us today.



Toll Free: 844.309.2376



Info@Teknipure.com

www.Teknipure.com